


City & State of Downlink Location    Amarillo TX

Diagram: 10/07/03

BLM Office                                    Amarillo Field Office

Diagram Contact                            Mr. Steve Baker

Diagram Code:                              AmarilloTX



Site Specific Instructions and Comments

VCR needs to be set on L1. Press Channel Up/Down to locate.  
Projection System needs to be set on Video Selection using the Remote Control.

PA Pot on AT2001 can be turned up (clockwise) to record this site's questions at the VCR.

Amarillo Field Office  
Amarillo TX